

Possessed Dresser



Front



Back

This was part of our "Exorcist Room" set. When the forbidden words were spoken, all sorts of stuff started happening in this room. The first physical effect was this dresser.

Two of the drawers started alternately banging in and out, which then led to other effects in sequence. It was pretty simple, but very effective.



A "U" shaped bracket is attached to the back of each drawer and a hole drilled to accept the push arms. The push arms are 1"X2"s about a foot long. This can be lengthened or shortened depending on how far you want the drawers to go out.



With one drawer in and one out, attach the push arms to the throw arm. All the wood arms should pivot freely, but make sure to double nut the bolts so they don't unscrew.

NOTE: The pipes don't have to be that big! This is just what I had laying around so I used it. PVC wouldn't be strong enough, but anything metal should be fine.

Obtained from
Omarshauntedtrail.com