

http://www.legendofthewood.com/2009coffin

Toe Pincher Coffin III





Critical Tools of the Trade:

- Table Saw
- Circular Saw
- Square
- Drill
- Hammer
- Wood Glue
- 1" Dry Wall Screws
- 1 1/4" Deck Screws
- Saw Horsestained from

The materials arshaunted trail.com

The project uses 15 - 72" 1" x 6" pressure treated fence panels. These can be purchased at Lowes and Home Depot. This is not the highest grade of wood. It is weathered and smells....PERFECT!!!!!

Screws are a must. For extra support all of the pieces are glued using Wood Glue.





This picture is of all the cuts made.

Another picture is of the cuts made.

The bottom and top spread out on the floor. Obtained from Omarshauntedtrail.com







The Side Panels

The top and bottom using the connectors

The top and bottom using the connectors Obtained from Omarshauntedtrail.com



The sides using the connectors

All the parts

Obtained from Omarshauntedtrail.com





The top and bottom using the connectors

All the parts ready for assembly

Obtained from Omarshauntedtrail.com

The finished bottom, sides, bottom, and top









Taking a test drive. Our model gives it a try.

The coffin handles. A brown hemp rope is perfect

Obtained from Assembling the sides using the 1" Dry Wall Screws

Assembling the sides using the 1" Dry Wall Screws







The finished product side by side with a cardboard version

Finished product with the lid open

Obtained from Omarshauntedtrail.com

Finished product with the lid open



Finished lid with a cross and leaf designs. The porcelain cross and the wooden leaf designs were purchased from our local craft store

Obtained from Omarshauntedtrail.com